



SWITCHES & ELECTRONICS



- | | | |
|---|--------|---|
| A | 2801-A | SWITCH 10AX 1G 1W |
| | 2801-B | SWITCH 10AX 1G 2W |
| | 2801-C | 10AX 1G INTERMEDIATE PLATE SWITCH |
| B | 2802-A | SWITCH 10AX 2G 1W |
| | 2802-B | SWITCH 10AX 2G 2W |
| C | 2803-A | SWITCH 10AX 3G 1W |
| | 2803-B | SWITCH 10AX 3G 2W |
| D | 2804-A | SWITCH 10AX 4G 1W |
| | 2804-B | SWITCH 10AX 4G 2W |
| E | 2800 | 1G BLANK PLATE |
| | 2824 | 2G BLANK PLATE |
| F | 2811 | BELL PUSH SWITCH 10A 1G |
| | 2811P | 10A PRESS SWITCH |
| | 2821 | D.P. SWITCH 20AX+NEON |
| G | 2821W | D.P. SWITCH 20AX+NEON(WATER HEATER) |
| | 2822 | D.P. SWITCH 20AX 2G+NEON |
| H | 2843 | D.P. SWITCH 32A+NEON |
| | 2845 | D.P. SWITCH 45A+NEON |
| I | 2877 | 200W HUMAN BODY INFRARED INDUCTION SWITCH (POWER INDICATOR) |
| J | 2871 | DIMMER UNIT 500W 1G 2W |
| | 2872 | DIMMER UNIT 500W 2G 2W |
| K | 2881 | FAN CONTROL 400VA 1G 2W |
| | 2882 | FAN CONTROL 400VA 2G 2W |

A	B	C
D	E	F
G	H	I
J	K	


SOCKET OUTLETS



- | | | |
|---|---|---|
| A | B | C |
| D | E | F |
- | | | |
|---|---------|-------------------------------|
| A | 2813 | BS SOCKET OUTLET 13A |
| B | 2813-S | BS SOCKET OUTLET 13A SW. |
| C | 2813-SL | BS SOCKET OUTLET 13A SW.+NEON |
| D | 2815-SL | BS SOCKET OUTLET 15A SW.+NEON |
| E | 2855-S | BS SOCKET OUTLET 5A SW. |
| F | 2816 | SCHUKO SOCKET OUTLET 16A |

SOCKET OUTLETS

G	H
I	J



- | | | |
|---|---------|---|
| G | 2832-SL | SOCKET OUTLET 13A SW.+NEON (JUST FOR USE IN HOTEL & OVERSEAS) |
| | 2842-SL | SOCKET OUTLET 13A SW.2G+NEON (JUST FOR USE IN HOTEL & OVERSEAS) |
| H | 2823 | BS SOCKET OUTLET 13A 2G |
| | 2823-S | BS SOCKET OUTLET 13A SW. 2G |
| I | 2823-SL | BS SOCKET OUTLET 13A SW. 2G+NEON |
| | 2841 | BS SOCKET OUTLET 32A SWITCH+NEON +13A SW.+NEON |
| J | 2842 | BS SOCKET OUTLET 45A SWITCH+NEON +13A SW.+NEON |

WEATHERSHIELD


A
B



- | | | |
|---|------|-----------------------------|
| A | 2878 | WATERSHIELD COVER (SHALLOW) |
| B | 2879 | WATERSHIELD COVER (DEEP) |

TELECOM

A	B	C
D	E	F



- | | | |
|---|--------|------------------------------------|
| A | 2817 | 1G TELEPHONE SOCKET (FCC STANDARD) |
| B | 2818 | 1G TELEPHONE SOCKET (BS STANDARD) |
| C | 2873 | TEL/PC WEB SOCKET OUTLET (RJ45/BT) |
| | 2874 | RJ11& BT TELEPHONE SOCKET OUTLET |
| D | 2875 | RJ11&RJ45 COMPUTER OUTLET |
| E | 2807-B | TV/FM SOCKET OUTLET |
| | 2807C | 2G TV SOCKETOUTLET |
| F | 2861 | RJ45 DATA OUTLET(1 MOD) |
| | 2862 | RJ45 DATA OUTLET(2 MOD) |


CONNECTION UNITS



- | | | |
|---|--------|--|
| A | 2860 | FUSE SPUR UNIT 13ASCREW FUSED (FRONT OUTLET) |
| B | 2860-S | FUSE SPUR UNIT 13ASW.(FRONT OUTLET) |
| C | 2825 | 25A CONNECTION UNIT (FRONT OUTLET) |
| D | 2825B | 25A CONNECTION UNIT (SIDE OUTLET) |

A	B	C
D		

DISTRIBUTOR:



Elegance Series 7mm

Elegance Series 7mm uses the unbreakable plastic, front plate colour is cool white.

The fixing screws are concealed by integral plastic caps, which ensure the products has a very clean look. Various products are available, including switches, sockets, telecommunication sockets, dimmers, inductive switches etc.























FUNG YIP ELECTRICAL MFG. LTD.













Elegance Series 7mm



APPEARANCE	CAT.NO.	DESCRIPTION
	2801-A 2801-B 2801-C	SWITCH 10AX 1G 1W SWITCH 10AX 1G 2W 10AX 1G INTERMEDIATE PLATE SWITCH
	2802-A 2802-B	SWITCH 10AX 2G 1W SWITCH 10AX 2G 2W
	2803-A 2803-B	SWITCH 10AX 3G 1W SWITCH 10AX 3G 2W
	2804-A 2804-B	SWITCH 10AX 4G 1W SWITCH 10AX 4G 2W
	2811 2811P	BELL PUSH SWITCH 10A 1G 10A PRESS SWITCH
	2821 2821W	D.P. SWITCH 20AX+NEON D.P. SWITCH 20AX+NEON (WATER HEATER)
	2822	D.P. SWITCH 20AX 2G+NEON
	2843 2845	D.P. SWITCH 32A+NEON D.P. SWITCH 45A+NEON
	2871 2872	DIMMER UNIT 500W 1G 2W DIMMER UNIT 500W 2G 2W
	2881 2882	FAN CONTROL 400VA 1G 2W FAN CONTROL 400VA 2G 2W

APPEARANCE	CAT.NO.	DESCRIPTION
	2850 2851	100W SLIGHT TOUCH TIME-DELAY SWITCH(TIME DELAY FUNCTION) 100W TOUCHING TIME-DELAY SWITCH(TIME DELAY FUNCTION)
	2877 2800	200W HUMAN BODY INFRARED INDUCTION SWITCH(POWER INDICATOR) 1G BLANK PLATE
	2824	2G BLANK PLATE
	2813 2813-S	BS SOCKET OUTLET 13A BS SOCKET OUTLET 13ASW.
	2813-SL 2855-S	BS SOCKET OUTLET 13ASW.+NEON BS SOCKET OUTLET 5ASW.
	2815-SL 2816	BS SOCKET OUTLET 15ASW.+NEON SCHUKO SOCKET OUTLET 16A
	2823	BS SOCKET OUTLET 13A2G
	2823-S	BS SOCKET OUTLET 13A SW. 2G
	2823-SL	BS SOCKET OUTLET 13A SW. 2G+NEON
	2841 2842	BS SOCKET OUTLET 32A SWITCH+NEON+13A SW.+NEON BS SOCKET OUTLET 45A SWITCH+NEON+13A SW.+NEON

APPEARANCE	CAT.NO.	DESCRIPTION
	2831-S 2832-SL	10A 2 PIN SWITCHED UNIVERSAL SOCKET SOCKET OUTLET 13A SW.+NEON (JUST FOR USE IN HOTEL & OVERSEAS)
	2842-SL	SOCKET OUTLET 13A SW.2G+NEON (JUST FOR USE IN HOTEL & OVERSEAS)
	2860 2860-S	FUSE SPUR UNIT 13A SCREW FUSED (FRONT OUTLET) FUSE SPUR UNIT 13A SW. (FRONT OUTLET)
	2825 2825B 2840	25A CONNECTION UNIT (FRONT OUTLET) 25A CONNECTION UNIT (SIDE OUTLET) 45A CONNECTION UNIT (SIDE OUTLET)
	2807-B 2807C	TV/FM SOCKET OUTLET 2G TV SOCKET OUTLET
	2817 2818	1G TELEPHONE SOCKET (FCC STANDARD) 1G TELEPHONE SOCKET (BS STANDARD)
	2873 2874 2875	TEL/PC WEB SOCKET OUTLET (RJ45/BT) RJ11 & BT TELEPHONE SOCKET OUTLET RJ11 & RJ45 COMPUTER OUTLET
	2861 2862	RJ45 DATA OUTLET(1 MOD) RJ45 DATA OUTLET(2 MOD)
	2899	SCV OUTLET
	2878 2879	WATERSHIELD COVER (SHALLOW) WATERSHIELD COVER (DEEP)